



COMPACTION WHEEL

OPERATION AND MAINTENANCE MANUAL



BRISBANE

PH: 07 3376 3177
SALES@NORMENG.COM.AU
787 BOUNDARY ROAD
DARRA QLD 4076

MELBOURNE

PH: 03 9775 1965
VICSALES@NORMENG.COM.AU
2/45 FRANKSTON GARDENS DRIVE
CARRUM DOWNS VIC 3201

SYDNEY

PH: 02 7246 7838
NSWSALES@NORMENG.COM.AU
2/3 CONTAPLAS STREET
ARNDELL PARK NSW 2148

NEW ZEALAND

PH: +64 7 889 7080
SERVICE@NORMENG.CO.NZ
14/2582 STATE HIGHWAY 26
MORRINSVILLE 3372

Contents

1	Introduction.....	1
2	Safety Definitions: Terms and Symbols.....	2
3	Safety Instructions.....	3
3.1	Important Points.....	5
4	Predelivery	6
4.1	Check Pickup Fit.....	6
4.2	Check Range of Motion	6
5	Assembly Instructions.....	7
5.1	Hitching Up the Compaction Wheel	7
5.2	Removing the Compaction Wheel.....	8
6	Operating Instructions	8
6.1	Specified Operations and Limitations.....	8
7	Maintenance and Care	9
7.1	Prior to Use.....	9
7.2	Routine Inspection (Every 12 Weeks).....	9
7.3	Greaseable Points	10
7.4	Outside Wheel Removal	10
7.5	Middle Wheel Removal	11
7.6	Securing the Wheels.....	12
8	Risk Assessment.....	13
9	Parts.....	19
9.1	Ordering Parts.....	19
9.1.1	Reference Information	19
10	Parts List	20
11	Appendices	22
11.1	Safety Sign Locations	22
12	Warranty.....	23
12.1	Definition.....	23
12.2	Warranty	23

1 INTRODUCTION



Compaction Wheel

Congratulations on purchasing a Norm Engineering Pty Ltd attachment. We have designed this compaction wheel for a long, productive, and safe life. Your attachment will provide you with years of service provided regular maintenance and correct usage is applied.

This manual offers a guide on how to safely assemble, mount, operate and maintain your compaction wheel. While the manual attempts to cover most situations, there are many unforeseen risks and events that are not included due to the capability of the compaction wheel. On this basis the owner and/or operator must determine if this attachment is suited for a particular purpose.

Norm Engineering Pty Ltd can accept no responsibility or liability for how you operate your equipment: we can only provide warning notes and safety precautions in relation to the standard operation of the compaction wheel.

The illustrations and data used in this manual were current at the time of printing but due to possible engineering and/or production changes, this product may vary slightly. Norm Engineering Pty Ltd reserves the right to redesign and/or change components as may be necessary without notification.

2 SAFETY DEFINITIONS: TERMS AND SYMBOLS

We will use the ANSI Z535.4-2011(R2017) standard for the definitions of signal words as described in conjunction with colours red, orange, and yellow. These are used with the Safety Alert Symbol:

- **Signal word**: Are defined as the words used in the signal word panel. The signal words for hazard alerting signs are “DANGER”, “WARNING”, and “CAUTION”. Safety notice signs use the signal word “NOTICE”. Safety instruction signs use signal words that are specific to the situation.
- **DANGER**: Indicates a hazardous situation, which, if not avoided, **will** result in death or serious injury. This signal word is to be limited to the most extreme situations. (White letters on a red background)

- **WARNING**: Indicates a hazardous situation, which, if not avoided, **could** result in death or serious injury. (Black letters on an orange background)

- **CAUTION**: Indicates a hazardous situation, which, if not avoided, **could** result in minor or moderate injury. (Black letters on a yellow background)

- **NOTICE**: Indicates information considered important, but **not** hazard-related (e.g., messages relating to property damage). (White letters on a blue background)

- **SAFETY INSTRUCTIONS**: Indicates a type of safety sign, where specific **safety-related instructions** or **procedures** are described. More definitive signal words are encouraged, where practical (e.g., SAFE SHUTDOWN PROCEDURE, SAFE OPERATING PROCEDURE). (White letters on a green background)


3 SAFETY INSTRUCTIONS



WARNING

Obey all the safety instructions listed in this section and throughout this manual. Failure to follow instructions could result in death or serious injury.

NOTICE

Before attempting any type of assembly operation, maintenance, or other work on or near this product:

- READ and COMPLETELY UNDERSTAND:
 - This manual,
 - The manuals provided with the power unit being used with this attachment.
- Read and understand all safety signs associated with the equipment being used.
- Know all your controls and know how to quickly stop all power unit movement, the attachment movement, and the engine in case of an emergency.

SAFETY IS YOUR RESPONSIBILITY AS THE OPERATOR OF THE EQUIPMENT

Inappropriate and/or irresponsible use of a compaction wheel may cause serious injury and trauma. The operator must have all relevant industry competencies, qualifications, certificates and/or licenses.

The operator must understand their responsibilities under the relevant acts and regulations of the governing body. Failure to comply with your legal obligations under the act may result in prosecutions against you.

As the equipment operator you are responsible to familiarise yourself, and anyone else who will assemble, operate, maintain, or work around this product with the safety information contained within this manual. You must make certain that all operators and maintenance personnel have a complete understanding of the full and exact contents of this manual and those of the power unit.

There are usually specific precautions and steps in the power unit operating manual to be taken to ensure your safety prior to engaging the attachment.

Conduct a job site survey during the planning phase of any construction project to identify potential hazards and develop and implement appropriate control measures to protect workers.

Accidents are preventable if the equipment operator is careful and responsible. No accident prevention program can be successful unless there is a wholehearted commitment and cooperation of the person who is directly responsible for the operation of the equipment.

Make sure anyone who will be installing, maintaining, repairing, removing, and/or storing this product applies the Workplace Health and Safety Act requirements. This includes ensuring that the person has been instructed in the safe operation of this product and of the power unit to which this attachment is likely to be attached.

Know and follow good work practices, some of these include:

- To optimise the physical environment such as having a well-lit, level surface that is clean and dry to work on.
- Use properly grounded, test and tagged electrical outlets and tools.
- Use the right tool for the job at hand.
- Make sure that your tools are in good condition for performing the required function.
- When using tools, wear the protective equipment specified by the tool manufacturer (hardhat, safety glasses, work gloves, protective shoe...)
- When the attachment has been out in the sun, remember to wear protective gloves as the metal will be hot to touch.
- Before starting, know the job duration, job complexity, and best procedure.
- Ensure workers have the capacity to do the job.
- Check that all hazards have been identified and control measures implemented.
- Clear communication so everyone present knows what is happening.
- Clear emergency stop procedure so there is no confusion in an emergency.
- Ensure the use of tyre stoppers and securing framework to stop the plant and plant attachment moving during maintenance.

3.1 IMPORTANT POINTS

When your power unit is used during any type of assembly, operation, maintenance, or other work on or near this product:

- Before leaving the operator's station or before beginning any type of work on this product, lower this product to the ground, apply your power unit's parking brake, stop the engine, remove the starter key, wait for all moving parts to stop, and then relieve all pressure in the hydraulic lines. Refer to your power unit's operating manual for instructions on preparing the equipment for hitching up an attachment and relieving hydraulic pressure in lines.
- Know your power unit's safe lifting and operating capacity and the weight of this product. (Check the parent machines operator manuals for safe operating limits).
- Only allow the operator to be around the power unit or this product when either is in motion. Ensure work area is clear of all personnel.
- Apply all safety guidelines in relation to the operator and the equipment.
- Only operate controls from the operator's station.
- Maintain operator presence at all times when the engine is running, or the product is raised on the power unit.
- Reduce speeds when additional weight and width need to be considered especially over rough ground.
- Consider the operating environment if dust is a concern reduce the machine speed.
- Whilst in motion keep the product close to the ground and under control.

4 PREDELIVERY

The following steps should be performed when fitting this attachment to a power unit for the first time. Failure to perform these checks may lead to damage of the attachment, the power unit and be a risk to safety. Warranty claims that arise as a result of skipping these steps may be challenged.

4.1 CHECK PICKUP FIT

Perform '5.1 Hitching Up the Compaction wheel' to check how the attachment fits the coupler. Check for the following:

- Does the hitch lock onto the pickups?
- Is it a tight fit?

4.2 CHECK RANGE OF MOTION

Carefully go through the parent machines full range of motion with the attachment. If unexpected contact occurs, contact Norm Engineering to discuss. Due to the capabilities of this product some contact with the machine may be unavoidable. In this case place the warning sticker provided on the attachment and inform the owner/operator.



5 ASSEMBLY INSTRUCTIONS

WARNING

Obey all instructions listed in this section of the manual. Failure to follow the instructions listed below could lead to serious injuries.

For any assistance with the following processes, please contact Norm Engineering.

5.1 HITCHING UP THE COMPACTION WHEEL

DANGER

All safety precautions pertaining to both the power unit and the compaction wheel need to be followed. Sufficient planning should be made prior to any work commencing in case of an emergency situation.

Step one: Before beginning any work on this product, lower the product to the ground on a firm level surface that is large enough to accommodate this product, the power unit and all workers involved in the hitching up the compaction wheel.



Step two: Refer to your power unit's operating manual for instructions on hitching up this attachment. Visually inspect to ensure the attachment is fully engaged to the power unit hitch.

Step three: Engage the locking mechanism. A visual inspection should be performed to confirm all locking systems are secured. Give the compaction wheel a few short sharp movements close to the ground to ensure it is engaged.

5.2 REMOVING THE COMPACTION WHEEL



All safety precautions pertaining to both the power unit and the compaction wheel need to be followed. Sufficient planning should be made prior to any work commencing in case of an emergency situation.

Step one: Remove the machine from anywhere near other personnel and onto a firm level surface large enough to safely accommodate this product, the power unit and all workers involved in removing the compaction wheel.

Step two: Rest the compaction wheel on the ground.

Step three: Disengage the locking mechanism. A visual inspection should be performed to make sure the compaction wheel is fully disengaged.

Step four: Refer to your power unit's operating manual for instructions on removing the attachment and confirm the hitch is fully disengaged from the compaction wheel.

Step five: Store safely.

6 OPERATING INSTRUCTIONS



When using the compaction wheel, ensure all personnel wear appropriate personal protective equipment at all times. All personnel must stand well clear of the compaction wheel during operation. Contact with the attachment, parent machine or flying debris and dust could cause injury to personnel working in the vicinity of the machine.

6.1 SPECIFIED OPERATIONS AND LIMITATIONS

The compaction wheel is to be used for compacting loose soil and refining trench edges. Misuse may damage the attachment or lead to injury and trauma.



The compaction wheel is **NOT** to be used:

- to carry people;
- as a lifting point;
- as a towing point;
- to pull or push over objects.

7 MAINTENANCE AND CARE

WARNING

Before commencing maintenance, place the attachment on level ground. Ensure enough area to perform maintenance on the attachment. Follow '5.2 Removing the compaction wheel'.

WARNING

After maintenance is complete, follow '5.1 Hitching Up the compaction wheel'.

7.1 PRIOR TO USE

Prior to use, the compaction wheel shall be visually inspected to verify the attachment is in an operational state. The inspection will check for:

- Signs of wear, including corrosive and abrasive wear.
- Markings are legible.
- Welds are not damaged, cracked or worn.
- All fasteners are in place and correctly torqued.
- Inspect the wear in the compaction foot.
- Grease all fittings – this needs to be performed on a daily basis.


7.2 ROUTINE INSPECTION (EVERY 12 WEEKS)

Routine inspections should include but is not limited to the following:

- Pins and bushes should be inspected for signs of excessive wear and replaced before the wear damages the structure of the compaction wheel.
- Inspect the attachment for wear, particularly around the compaction feet, and seek advice on repairs if wear is excessive.
- Check to ensure attachment markings are legible.

7.3 GREASEABLE POINTS

The location of both greaseable points can be found in the diagram below. As part of 7.1 Prior to Use, ensure these points have been greased prior to use.



7.4 OUTSIDE WHEEL REMOVAL

Step one: Lay the compaction wheel onto a firm level surface large enough to safely accommodate this product and all workers involved in removing the wheel. Secure the main base and wheels.



- The wheels and main base are heavy and can be difficult to control if not sufficiently secured.

Step two: Loosen all shaft locking device (SLD) bolts in several stages to ease off the pressure gradually.

Step three: The SLD is designed with self-releasing tapers, but if device is still locked after loosening then place light taps to three equally spaced bolt heads.

Step four: Remove the outside wheel from the SLD before sliding the SLD off the shaft.

7.5 MIDDLE WHEEL REMOVAL

Step one: Lay the compaction wheel onto a firm level surface large enough to safely accommodate this product and all workers involved in removing the wheels. Secure the main base and wheels.



- The wheels and main body are heavy and can be difficult to control if not sufficiently secured.

Step two: Unbolt and separate the bearing hubs from the main base.


Step three: Follow “7.4 Outside Wheel Removal” to remove the outside wheel which faces the bolt side of the centre SLD (The bolt side of the SLD is the side with the added 8mm protection plate on the wheel).

Step four: Remove the spacer bushes (green) and bearing hub from the shaft.

Step five: Using the same loosening method used on the outside wheel gradually reduce the pressure in the centre SLD.

Step six: The SLD is designed with self-releasing tapers, but if device is still locked after loosening then place light taps to three equally spaced bolt heads.

Step seven: Remove the wheel from the SLD before sliding the SLD off the shaft.



7.6 SECURING THE WHEELS

Step one: Clean and lightly oil rings, shaft and wheel hub contact surfaces.

Step two: Place the SLD inside the wheel hub and slide into position on the shaft.

Step three: Tighten bolts in a crosswise pattern until play is taken up but sliding movement is still possible.


Step four: Confirm wheel position on the shaft and the teeth position with respect to the other wheels as seen below.

Step five: Set a torque wrench to $M_a=40\text{Nm}$ for 60mm shaft, or $M_a=79\text{Nm}$ for 70mm shaft.

Step six: Using set torque wrench repeat alternating crosswise pattern with $\frac{1}{4}$ turns until $\frac{1}{4}$ turns can no longer be achieved.

Step seven: Repeat for two more passes once bolts are locked.

Step eight: Set torque wrench to specified torque $M_a=38\text{Nm}$ or 60mm shaft, or $M_a=75\text{Nm}$ for 70mm shaft and check all bolts (no bolt should turn at this point. If so repeat **Step seven**. for two more passes).



8 RISK ASSESSMENT

Assessment Team: Norman Pesch, John Pesch, Sam Ramsden

Date of Assessment: 19/04/2022

Manufacturer: Norm Engineering Pty Ltd

Location: Brisbane

Contact Person: Norman Pesch

Attachment: Compaction Wheel

Weight: 160-720kg

Intended use: Compacting Earth

Construction material: Steel

Air Operated: NO

Hydraulic Operated: NO

Manually operated: YES

NOTE: When assessing Risk, you MUST consider the following

Inherent Risk:

(Risk before ANY controls). I.e., Before guarding / safety features are fitted.

Residual Risk:

(Risk after controls are fitted). I.e., after guarding / safety features are fitted.

Non Standard Operating Risk:

(Cleaning, Maintenance). I.e., What other risks can these tasks create.

Predictable Misuse:

I.e., What risks could occur due to misuse of the attachment.

HAZARD INFORMATION

The plant must be assessed against the hazards listed for the probability of harm to operators working in close proximity and the environment.

Probability

- A – Common or repeating occurrence
- B – Known to occur or “It has happened”
- C – Could occur, “I’ve heard of it happening”
- D – Not likely to occur
- E – Practically impossible

Consequence

- 1 – Catastrophic – Fatalities
- 2 – Major – Major injury, LTI
- 3 – Moderate – Minor Injury
- 4 – Minor – First aid, slight injury
- 5 – Insignificant – Minimal risk of injury

	A	B	C	D	E
1	H	H	H	S	S
2	H	H	S	S	M
3	H	H	S	M	L
4	H	S	M	L	L
5	S	S	M	L	L

H = High

S = Significant

M = Medium

L = Low

Entanglement:

Can anyone's hair, clothing gloves, necktie, jewellery, rags, and other materials become entangled with moving parts of plant, or materials in motion? People in close proximity and not following SOP while the plant and plant attachment are in use can become entangled in the rotating components.	Yes ☒ No ☐	A	☐	1	☐	High Significant Medium Low	☐ ☐ ☒ ☐
		B	☐	2	☒		
		C	☐	3	☐		
		D	☒	4	☐		
		E	☐	5	☐		

Crushing:

Can anyone be crushed due to falling, uncontrolled or unexpected movement of plant attachment or its load, lack of capacity to slow, stop or immobilise the plant, tipping or rolling over, parts of plant attachment collapsing, contact with moving parts during testing, inspection, maintenance, cleaning, or repair, thrown off, under or trapped between plant and materials or fixed structures? People in close proximity to the plant and plant attachment during operation could be crushed if the operator is not being sufficiently observant, or control over the plant is lost.	Yes ☒ No ☐	A	☐	1	☒	High Significant Medium Low	☒ ☐ ☐ ☐
		B	☐	2	☐		
		C	☒	3	☐		
		D	☐	4	☐		
		E	☐	5	☐		

Cutting, Stabbing, Puncturing:

Can anyone be cut, stabbed, or punctured by coming in contact with moving plant or parts, sharp or flying objects, work pieces ejected, work pieces disintegrated, or other factors not mentioned?	Yes ☐ No ☒	A	☐	1	☐	High Significant Medium Low	☐ ☐ ☐ ☐
		B	☐	2	☐		
		C	☐	3	☐		
		D	☐	4	☐		
		E	☐	5	☐		

Striking:

Can anyone be struck by moving objects due to plant or work pieces being ejected or disintegrated, mobility, uncontrolled or unexpected movement of the plant or other factors? People in close proximity to the plant and plant attachment during operation could be seriously hurt if they came into contact with the plant, or plant attachment if the operator is not being sufficiently observant, or control over the plant is lost.	Yes ☒ No ☐	A	☐	1	☐	High Significant Medium Low	☐ ☒ ☐ ☐ ☐
		B	☐	2	☒		
		C	☒	3	☐		
		D	☐	4	☐		
		E	☐	5	☐		

Slipping, Tripping, Falling:

Can anyone using the plant or in the vicinity of the plant, slip, trip or fall due to the working environment or other factors? poor housekeeping, dust on the floor around machines, slippery or uneven work surfaces or lack of guardrails.		Yes	No	A	☐	1	☐	High	☐
				B	☐	2	☐	Significant	☒
				C	☒	3	☒	Medium	☐
				D	☐	4	☐	Low	☐
				E	☐	5	☐		
People standing on the plant or plant attachment while disconnected and laying on its side could slip from it.									

Shearing:

Can anyone's body parts be cut off between two parts of the plant, or between a part of the plant and a work piece or structure? For example, on a metal guillotine can a finger fit under the guard.		Yes	No	A	☐	1	☐	High	☐
				B	☐	2	☒	Significant	☒
				C	☐	3	☐	Medium	☐
				D	☒	4	☐	Low	☐
				E	☐	5	☐		
People in close proximity and not following SOP while the plant and plant attachment are in use can have body part caught between rotating components.									

Friction:

Can anyone be burnt due to contact with moving parts or surfaces of the plant, or material handled by the plant? For example, on the grinder is there more than 1 mm gap between the tool rest and the wheel?		Yes	No	A	☐	1	☐	High	☐
				B	☐	2	☐	Significant	☐
				C	☐	3	☐	Medium	☐
				D	☐	4	☐	Low	☐
				E	☐	5	☐		
If maintenance procedures aren't followed and the grease nipples aren't greased the use of the plant attachment might lead to heated pivot section.									

High Pressure Fluid:

Can anyone come into contact with fluids under high pressure, due to plant failure or misuse of the plant?		Yes	No	A	☐	1	☐	High	☐
				B	☐	2	☐	Significant	☐
				C	☐	3	☐	Medium	☐
				D	☐	4	☐	Low	☐
				E	☐	5	☐		

Electrical:

Can anyone be injured by electrical shock or burnt due to damaged or poorly maintained leads or switches, water near electrical equipment, working near or contact with live electrical conductors, lack of isolation procedures or the factors not mentioned? For example, are any switches broken, is there a red emergency stop? Can each machine be locked off for repairs?		Yes	No	A	☐	1	☐	High	☐
				B	☐	2	☐	Significant	☐
				C	☐	3	☐	Medium	☐
				D	☐	4	☐	Low	☐
				E	☐	5	☐		

Dust:

Can anyone suffer ill health or injury due to exposure to dust? For example, cutting, living silica Lack of vision – External influences causing the dust. Plant operation causing the dust.	Yes	No	A	☐	1	☐	High	☐
			B	☐	2	☐	Significant	☐
			C	☐	3	☐	Medium	☐
			D	☐	4	☐	Low	☐
			E	☐	5	☐		

Noise:

Can anyone suffer hearing discomforts while the plant is in use? For example, the plant is noisy, and it is difficult to hear.	Yes	No	A	☐	1	☐	High	☐
			B	☐	2	☐	Significant	☐
			C	☐	3	☐	Medium	☐
			D	☐	4	☐	Low	☐
			E	☐	5	☐		

Vibration:

Can anyone suffer injury due to the vibration of the plant?	Yes	No	A	☐	1	☐	High	☐
			B	☐	2	☐	Significant	☐
			C	☐	3	☐	Medium	☐
			D	☐	4	☐	Low	☐
			E	☐	5	☐		

Environmental:

Can the plant operation cause an environmental issue? For example – pollution, waste materials, noise.	Yes	No	A	☐	1	☐	High	☐
			B	☐	2	☐	Significant	☐
			C	☐	3	☐	Medium	☐
			D	☐	4	☐	Low	☐
			E	☐	5	☐		

Risk Evaluation

Overall risk category of plant:	High	Significant	Medium	Low
---------------------------------	------	-------------	--------	-----

Risk Controls

Most Desirable

- | | |
|--|---|
| <div style="display: flex; align-items: center;"> <div style="width: 10px; height: 100px; border-left: 1px solid black; margin-right: 5px;"></div> <div> <ul style="list-style-type: none"> • Elimination • Substitution • Engineering Controls • Isolation • Administrative Controls </div> </div> <div style="margin-top: 10px;"> <div style="display: flex; align-items: center;"> <div style="width: 10px; height: 10px; background-color: black; margin-right: 5px;"></div> <div>• PPE</div> </div> </div> | <ul style="list-style-type: none"> - The best way to eliminate the risk is to remove the hazard. - Substitute the hazardous plant with a safer part, alternative process. - Design modification, installation of guarding, automation/ventilation. - Isolate the plant, barricades, crossing, bunting, etc. - Permits, clearances, lock out systems, certification. - Short term control measure. |
|--|---|

Least Desirable

Hazard	Controls
Entanglement	Isolation - Ensure the operating and maintenance manual provided with the plant attachment recommends the operator of the plant always follows SOP. The operator must make everybody working in the vicinity of the attachment aware of the dangers and only operate if people are a safe distance away. PPE – Ensuring all people who will be in the vicinity of the plant attachment during operation be wearing clothes with no loose ends that can become entangled in the plant attachment.
Crushing, Striking	Isolation – Ensure the operating and maintenance manual provided with the plant attachment recommends the operator of the plant always follows SOP. The operator must make everybody working in the vicinity of the attachment aware of the dangers and before moving the plant ensure people are safe distance away. PPE – The use of the correct PPE for the worksite will minimize the damage caused by an incident. A hard hat, steel cap boots and tough worksite clothes as an example. PPE – The use of high visibility PPE will help reduce the case of incidents occurring from impaired vision or operator distraction.
Slipping, Tripping, Falling	Isolation – Ensure the operating and maintenance manual covers the correct way to handle the plant attachment and standing on the attachment is listed under misuse. PPE – Wearing the correct work boots will reduce chances of slipping.
Shearing	Isolation – Ensure the operating and maintenance manual provided with the plant attachment recommends the operator of the plant always follows SOP. The operator must make everybody working in the vicinity of the attachment aware of the dangers and before moving the plant ensure people are safe distance away. Administrative Controls – A warning sticker should be placed in a visible position on the plant attachment highlighting the potential risk.

Any Modification to Plant Attachment Voids Risk Assessment

Purchaser and User are required to conduct their own risk assessment to identify hazards prior to use.

This risk assessment does not necessarily cover all possible hazards associated with this product and should be utilized in conjunction with the purchasers and users individual risk assessments to identify all environmental, health, and safety risks associated with specific tasks, locations, and personnel.

9 PARTS

QUALITY BACKUP

*We manufacture 90% of our parts inhouse.
This means we can get your parts to you... quickly.*

9.1 ORDERING PARTS

For ordering parts contact either your dealer or Norm Engineering directly. Contact details are included at the front of this manual. To assist, note the details of your compaction wheel in the spaces provided under *Section 9.1.1 Reference Information*.

9.1.1 REFERENCE INFORMATION

Always refer to the model and serial number when ordering parts or requesting from you dealer. The serial number for this product is located on the identification place of your compaction wheel.

Model Number:

.....

Make:

.....

Serial Number:

.....

Date Purchased:

.....

10 PARTS LIST

When ordering replacement parts, please include the following information:

- The machine make and model
- The serial number on the attachment
- The item number, as indicated by the following figures and tables.
- Parts with a part number of “.” indicate a component that varies dependent on machine make and model. A serial number and item number is essential if ordering these parts.


Items numbers with a “R” before the number indicate parts that require specialty tools and some knowledge in fabrication and welding to replace.

COMPACTION WHEEL PARTS LIST

Item	Part Number	QTY	Description	Diagram
1	.	1	MAIN BASE	1
2	.	2	BEARING HUB	1
3	.	3	COMPACTION WHEEL	1
4	.	1	PICKUP MOUNTING PLATE	1
5	.	4	WHEEL SPACER BUSH	1
6	.	4	BRONZE BUSH INSERT	1
7	.	1	CENTRE BAR PIN	1
8	.	2	PICKUP PIN	1
9	.	3	SHAFT LOCKING DEVICE	1
10	.	4	RADIAL OIL LIP SEAL	1
11	NS2001	2	3/8" GREASE NIPPLE	1
12	-	12	BOLT KIT – PICKUP MOUNTING PLATE	1
13	-	8	BOLT KIT – BEARING HUB	1
14	-	2	BOLT KIT – PICKUP PIN	1
R1	.	4	PICKUP BUSH	1
R2	.	2	PICKUP RETAINER	1

COMPACTION WHEEL

THE PRODUCT IMAGES ARE FOR ILLUSTRATIVE PURPOSES ONLY
AND MAY NOT BE AN EXACT REPRESENTATION OF THE PRODUCT.
NORM ENG. RESERVES THE RIGHT TO CHANGE PRODUCT IMAGES
AND SPECIFICATIONS AT ANY TIME WITHOUT NOTICE.



11 APPENDICES

11.1 SAFETY SIGN LOCATIONS

Item	Description
1	Warning Pinch point
2	Warning Attachment can contact machine
3	Danger Read the manual



ITEM 1



ITEM 2



ITEM 3

Instructions

- Keep all safety signs clear and legible.
- Replace all missing, illegible, or damaged safety signs.
- When replacing parts which have safety signs attached make sure the replacement part has the safety sign.

12 WARRANTY

12.1 DEFINITION

“Dealer” means a dealer that purchases products directly from Norm Engineering Pty Ltd.

“End consumer” means a consumer that purchases products either directly from Norm Engineering Pty Ltd or directly from a “dealer” as defined above.

“Products” includes goods and services.

12.2 WARRANTY

Norm Engineering Pty Ltd welcomes you as a purchaser of its products. All Norm Engineering products are designed to ensure the highest standards, reliability, and performance.

Norm Engineering Pty Ltd warrants hydraulic cylinders against defects in manufacture for a period of twelve months from date of sale by the dealer or Norm Engineering Pty Ltd to the end consumer. The warranty in relation to hydraulic cylinders ceases upon the occurrence of damage to the piston rod of the hydraulic cylinder.

No warranty applies to hoses, tubes, and fittings in relation to any of the products.

Norm Engineering Pty Ltd warrants all its other products against defects in manufacture for a period of twelve months from the date of sale by the dealer or Norm Engineering Pty Ltd to the end consumer.

Norm Engineering Pty Ltd will, subject to the terms of this warranty, in relation to defective goods:

- a) replace the defective goods at no cost to the end consumer; or
- b) repair the defective goods at no cost to the end consumer; or
- c) pay the cost of having the defective goods repaired.

Norm Engineering Pty Ltd will, subject to the terms of this warranty, in relation to defective services:

- a) supply the services again to the end consumer at no cost to the end consumer; or
- b) pay the cost of having the service supplied again to the end consumer.

Warranty claims may be sent either to Norm Engineering Pty Ltd., P.O. Box 178, Mt Ommaney, Qld. 4074 or to the dealer.

All warranty periods shall commence from the date of sale by Norm Engineering Pty Ltd or the dealer to the end consumer. It is the end consumer's responsibility to establish the date of sale of the product to the end consumer by the dealer.

The end consumer may establish the date of sale by producing to Norm Engineering Pty Ltd the dated contract of sale between the end consumer and the dealer with its warranty claim.

If the end consumer is not able to establish the date of sale of the product to the end consumer by the date of its warranty claim, the warranty period shall be deemed to commence from the date of sale of the product by Norm Engineering Pty Ltd to the dealer.

This warranty will not apply if the end consumer does not use the product in accordance with Norm Engineering Pty Ltd's recommendation.

This warranty will not apply if the end consumer does not use products applied or fitted to any machine, equipment, or plant, in accordance with Norm Engineering Pty Ltd's operating recommendation for the product.

This warranty does not apply to any loss or damage caused through consequential neglect. Unless the end consumer indicates to Norm Engineering Pty Ltd prior to purchasing the product that it intends to use the product for a particular purpose, there is no implied warranty that the product will fit for that particular purpose. Ask Norm Engineering for clarification of the intended use is not included in the manual.

Only a dealer authorised in writing, or issued with an order number, by Norm Engineering Pty Ltd may carry out warranty repairs. Prior written approval must be obtained from Norm Engineering Pty Ltd before warranty repairs are carried out. Norm Engineering Pty Ltd will not recognise any warranty claim for reimbursement of repair costs unless the repairs have been carried out by an authorised dealer with prior written approval from Norm Engineering Pty Ltd to carry out the repairs.

Norm Engineering Pty Ltd limits its liability, as follows:

1) Pursuant to Section 68A of the Trade Practices Act 1974, this clause applies in respect of any of the goods or services supplied under this contract which are not of a kind ordinarily acquired for personal, domestic, or household use or consumption, provided that this clause will not apply if the end consumer establishes that reliance on it would not be fair and reasonable.

2) Liability for breach of a condition or warranty implied into this contract by the Trade Practices Act 1974 other than a condition implied by Section 69 is limited:

a) In the case of goods, to any one of the following as determined by Norm Engineering Pty Ltd:

- i. the replacement of goods
- ii. the repair of the goods
- iii. the payment of the cost of having the goods repaired, excluding travelling and freight charges.

b) In the case of services, to any one of the following as determined by Norm Engineering Pty Ltd.

- i. the supplying of the services again; or
- ii. the payment of the cost of having the services supplied again

Expenses incurred by the end consumer in connection with making a warranty claim shall be borne by the end consumer unless otherwise agreed by Norm Engineering Pty Ltd.

To the extent permitted by law, all implied conditions, and warranties in the contract of sale between Norm Engineering Pty Ltd and the end consumer are hereby excluded.

The benefits conferred by this warranty on the end consumer are in addition to all other legal rights and remedies that the end consumer has in respect of the products.

Contracts of sale for products, and this warranty are submitted to the exclusive jurisdiction of the courts of Queensland.

Notes:

This image shows a single sheet of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Notes:

This image shows a single sheet of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.



WARRANTY NOTICE

DEALER:

STATE: SIGNED:

END CONSUMER:

NAME:

ADDRESS:

.....

.....

STATE: POSTAL CODE:

PHONE: SIGNED:

DATE OF SALE TO THE END CONSUMER:/...../.....

DESCRIPTION OF PRODUCTS:

.....

.....

.....

SERIAL NO:

DELIVERY DOCKET NO:

DELIVERY DATE:/...../.....

NOTE: THIS FORM IS TO BE COMPLETED BY THE DEALER

AND RETURNED TO: NORM ENGINEERING - P O BOX 178

MT OMMANEY, BRISBANE, QUEENSLAND, AUSTRALIA, 4074